

S86182 TEAK LIFE DETERGENTE



Ready for use



By brush



By roller

Description

Product with a high detergent power, especially formulated to remove salt deposits, oil and fat stains, from teak boat decks.

Characteristics

- High detergent power.
- Low foaminess

Substrate preparation

Wood

Rinse teak with fresh water, apply uniform detergent on the surface, allow to act for 5-10 minutes. Brush with a nylon broom and rinse repeatedly with fresh water. Avoid using metallic brooms, which could stain the wood due to metallic residue oxidation.

Application

By brush or by roller.

Mixing ratio

Ready for use

N° of coats: 1

TECHNICAL DATA SHEET N° S158-GB
UPDATED 03/2010

All information here included is the result of carefully controlled tests and expresses our best and up to date knowledge. This news is given only a guide, so the firm cannot be accountable for further results. Furthermore it cannot be used as a contestation related to the use of the described product. All this is due to the fact that use conditions are not under our control.